































## Installation der Berührungsschutzmodule für GEOS Schaltschränke

Installation of a module for the protection against accidental contact for GEOS switch cabinets

Installation des modules de protection contre le contact pour armoires de commande GEOS

<b>GEOS-S 3030</b>  722-084-01  722-083-01	<b>GEOS-S 4050</b>  Ecken ausbrechen Break out corner Rompre le coin	
<b>GEOS-S 3040</b>  722-087-01  722-087-01 } Set 722-097-01	 722-091-01 722-092-01 722-091-01 } Set 722-098-01	 722-093-01  722-093-01 722-093-01 
 722-087-01  722-088-01  722-088-01  722-087-01	 722-091-01 722-093-01 722-093-01 	 722-093-01  722-092-01 722-091-01
 722-087-01  722-088-01  722-088-01  722-087-01  722-088-01  722-088-01	 722-093-01  722-092-01 722-093-01 	 722-091-01 722-092-01 722-093-01 
<b>1</b>  Ecken ausbrechen Break out corner Rompre le coin	<b>2</b> Montage Assembly Montage  Click!	Demontage Disassembly Démontage 